


# GYMKANA

## PARTS LIST



\*Please note, not all parts are available for purchase





GYMKANA 994

KEYLINE

BLANCHI 1770 GROUP



10




11



12

13

14



22



23



24



18



17

25



29



28



27



26



Number	Part Number	Description
1	BI910	Console BI910
2	RIC10744B	Console Support
3	RIC10740B	Back Cover
4	RIC10741B	Clear Shield
5	RIC10742B	Chip Tray
7	RIC11557B	Clear Shield Fixing Kit
6	RIC06570B	Emergency Stop Switch
8	RIC10862B	Internal RJ25 Cable
9	RIC10863B	Console Cable Connection
10	RIC10743B	Z Axis Cover
11	RIC10715B	Tracer Knob
12	RIC11018B	Cutter Spindle
13	RIC07786B / RIC05274B	2mm Cutter (V037) / 1.5mm cutter (V012)
14	RIC11110B	T08 Tracer
15	RIC05354B	Rubber Feet (set of 4)
16	B9980	Mounting Kit
17	RIC11116B	U Clamp Top Plate
18	OPZ11114B	U Clamp
19	OPZ08099B	J Clamp – 8 cut Tibbe
20	OPZ09523B	H Clamp – 6 cut Tibbe
21	OPZ11279B	V Clamp Kit (includes RIC05274B cutter)
22	OPZ11088B-BS	M Clamp Kit (includes A/B side adaptor)
23	OPZ11086B	VATS S/V Adaptor for M Clamp
24	OPZ10795B	K Clamp Kit (includes V055 cutter) – only available through Snap-on
25	RIC10764B	Power Supply
26	RIC10876B	Belt
27	RIC11204B	Gymkana Tool Kit
28	B9979	Anti-Glare Console Screen Protector
29	RIC08515B	U Clamp Tip Stop